



### Replacement Parts For J5514-18

	Part #	Description	# on Unit
<b>1</b>	<b>J5514R01-18</b>	PIN L67	2 / Ea.
<b>2</b>	<b>J5514R02-18</b>	Bracket	2 / Ea.
<b>3</b>	<b>J5514R03-18</b>	O-Clip	3 / Ea.
<b>5</b>	<b>J5514R05-18</b>	Rotary Head	1 / Ea.
<b>8</b>	<b>J5514R08-18</b>	Castor Kit	4 / Ea.
<b>9</b>	<b>J5514R09-18</b>	Polypropylene Cover	1 / Ea.
<b>13</b>	<b>J5514R13-18</b>	Brush Skirt	1 / Ea.
<b>15</b>	<b>J5514R15-18</b>	Spray Arm	1 / Ea.
<b>21</b>	<b>J5514R21-18</b>	Spray Gun	4 / Ea.
<b>26</b>	<b>J5514R26-18</b>	Plastic Block	2 / Ea.
<b>27</b>	<b>J5514R27-18</b>	Handle Grip	1 / Ea.
<b>29</b>	<b>J5514R29-18</b>	Plastic Bracket	1 / Ea.
<b>30</b>	<b>T25025S2M</b>	Replacement Nozzles	2 / Ea.

\*More replacement parts are available upon request.